



DRAWER SLIDE EXCHANGE

Damaged slide Removal



Extend slide all the way out to expose two of the three screws which retain the slide to cabinet interior. With a phillips screw driver, remove these screws.



To remove the third screw, push the slide in approximately 4 inches.

Install new slides in reverse order of removal procedure

